



# **HZ MINIMALIST SERIES** **(1-SIDED/2-SIDED)** INSTALLATION GUIDE



# HZ MINIMALIST SERIES

## INSTALLATION GUIDE

**RECOMMENDED TOOLS/ HARDWARE:** Tape measure, Level Pencil, Drill, Stud finder, 5/16" Hex Head Bit, 13mm Nut Setter (for Pegs/Locknuts)

**PROVIDED HARDWARE:** Mounting Jig, 13mm Nut Driver (for Pegs/Locknuts)

## PACKAGE CONTENTS

(1-Sided Kits)		(2-Sided Kits)	
QTY	Description	QTY	Description
1	Post System	1	Post System
20	Mounting Plate	40	Mounting Plate
50	Mounting Locknuts	100	Mounting Locknuts
40	HZ Wine Pegs	80	HZ Wine Pegs
50	Hex-Head Screws	100	Hex-Head Screws

## INSTALLATION STEPS

**IMPORTANT:** Before installing, check package contents for missing or damaged items.

### STEP 1: LOCATE DESIRED AREA TO INSTALL RACK.

Start by gathering your tools and locating the desired location of the telescopic post's mounting. Once this has been determined, measure and mark the mounting points.

### STEP 2: IDENTIFY APPROPRIATE MOUNTING HARDWARE.

Identify the appropriate floor & ceiling mounting hardware for your unique application (drywall, stucco, concrete, brick)

### STEP 3: BEGIN TO DRILL HOLES FOR POST MOUNTING.

Using the appropriate tools and floor and ceiling mounting hardware, begin drilling holes at the previously designated marked points.

### STEP 4: ASSEMBLE TELESCOPIC POST SYSTEM.

Slide the 4ft insert into the 7ft hollow base, and prepare to place the post into your desired mounting location.

### STEP 5: ALIGN & SECURE POST SYSTEM.

Align and secure the post to the ceiling. (using appropriate anchors), Now anchor the Insert to the floor (using appropriate anchors). Make sure the post is perfectly vertical and tightly secured.

**IMPORTANT NOTE:** The 7ft hollow base should be affixed to the floor, not the ceiling.

### STEP 6: PLACE LOCKING HEX-HEAD BOLT ON THE POST.

Once the post system has been secured to the floor and ceiling, place the locking hex-head bolt into the holes located at the top of the post.

### STEP 7: DRILL INITIAL PILOT HOLES FOR THE FIRST MOUNTING PLATE.

Beginning where you desire your first mounting plate to be placed (start from the bottom of the post), use the mounting jig to drill the initial set of pilot holes. Repeat this process all the way up your post, keeping consistent spacing with the mounting jig.

### STEP 8: ATTACH THE FIRST MOUNTING PLATE TO THE POST, THEN REPEAT.

Install the Mounting Plates to the frame using the hex head screws provided in the accessory kit at your pre-drilled pilot holes. Ensure the mounting plate is level and aligned. Repeat steps 7-8 all the way up your post.

### STEP 9: ASSEMBLE MINIMALIST MOUNTING PLATES, PEGS, & LOCKNUTS.

Insert the pegs through the mounting plate and hand-tighten the nuts to the pegs. Once all pegs & nuts have been secured to the mounting plates, utilize a wrench or the provided sockets to tighten all pegs. Repeat this step as needed.

### STEP 10: REPEAT STEPS 7-9 ON BACK SIDE (2-SIDED APPLICATIONS ONLY).

### STEP 11: ADD WINE BOTTLES & ENJOY!



1-Sided Minimalist Series



2-Sided Minimalist Series



# HZ MINIMALIST SERIES

## CLEARANCE GUIDE



**\*Disclaimer: The dimensions provided are optimized for California standard wine bottle sizes; please verify bottle dimensions prior to plate installation.**

