6_3-100-4575-4575 10 COLUMN WALL DISPLAY ASSEMBLY INSTRUCTIONS





STEP 1.
ATTACH (4) SPACER BARS TO BACKSIDE OF LEFT,
RIGHT AND CENTER LADDERS. BOTTOM SPACER TO
BE FLUSH WITH BOTTOM OF LADDERS. THE (2)
CENTER SPACER BARS TO ALIGN WITH BOTTLE
SUPPORTS. TOP SPACER BAR TO BE FLUSH WITH
BOTTOM OF BOTTLE SUPPORTS.



STEP 3.
ATTACH DOUBLE SPACER BAR TO TOP
FRONT OF DISPLAY. ALIGN TOP OF NOTCHED
AREA WITH TOP OF BOTTLE SUPPORTS





STEP 2.
FLIP DISPLAY OVER. ATTACH (3)
REMAINING SPACER BARS TO FRONT OF
DISPLAY. ALIGN BOTTOM AND CENTER
SPACER BARS AS STATED IN STEP 2.