




COLD AIR CUTOUTS





- ① RETURN AIR INTAKE - LEFT (DUCTABLE)
- ② COLD AIR EXHAUST - FRONT (DUCTABLE)
- ③ RETURN AIR INTAKE - BOTTOM (NON-DUCTABLE)
- ④ COLD AIR EXHAUST - BOTTOM (NON-DUCTABLE)

NOTE: AIR CUTOUTS SHOWING SLOTTED GRILLS ARE NON-DUCTABLE. NEVER USE GRILLS ON AIR CUTOUTS THAT WILL BE DUCTED. IF USING OPTION 4: COLD AIR EXHAUST - FRONT, THE FRONT GRILL COVERING THE FACE OF THE UNIT MUST BE REMOVED.




HOT AIR CUTOUTS



- ⑤ FRESH AIR INTAKE - RIGHT (DUCTABLE)
- ⑥ HOT AIR EXHAUST - REAR (DUCTABLE)
- ⑦ HOT AIR EXHAUST - TOP 1 (DUCTABLE)
- ⑧ HOT AIR EXHAUST - TOP 2 (NON-DUCTABLE)
- ⑨ FRESH AIR INTAKE - TOP (DUCTABLE)

NOTE: AIR CUTOUTS SHOWING SLOTTED GRILLS ARE NON-DUCTABLE. NEVER USE GRILLS ON AIR CUTOUTS THAT WILL BE DUCTED.



2127E_R02