## ASSEMBLY INSTRUCTIONS Double Deep 15 3/4" Modular Racking

Thank you and CONGRATULATIONS for purchasing this fine quality product. Properly assembled and installed, your racking will enhance you wine collection for many years to come. To assemble your racks, please check to ensure all necessary parts have been included and follow the assembly instructions closely. if you have any questions or problems, please call us at 1-845-658-7181, Monday through Friday 9am to 5pm EST






If you are planning to stain or finish your racking we recommend you do so BEFORE assembly for best results.



\*Note: Instructions shown for a 6 column rack. Assembly procedure remains the same for alistandard

## **PARTS LIST**



All individual bottle racks are designed to be assembled with a nail gun, using either 18 gauge 1 1/2" brad nails or similar finishing nail. Nails are not included.

If you purchased pre-drilled screw assembly. 1 1/2" Phillips head screws will be supplied in your order.


SPACER BAR ASSEMBLY (Various Lengths) SPACER BAR SCREW ASSEMBLY (Various Lengths)

## PACKAGE CONTENTS SKU PRODUCT NAME **MIDDLE END** SPACER SCREWS LADDERS LADDERS **BARS** (if used) 8 3-000-0525-1575-DD 4 8 1 Column 15 3/4" Mod. Double Deep Individual Racking 0 2 2 8 3-000-0975-1575-DD 2 Column 15 3/4" Mod. Double Deep Individual Racking 1 4 12 8 3-000-1425-1575-DD 2 2 3 Column 15 3/4" Mod. Double Deep Individual Racking 4 16 2 8 3-000-1875-1575-DD 4 Column 15 3/4" Mod. Double Deep Individual Racking 3 4 20 8 3-000-2325-1575-DD 4 2 4 5 Column 15 3/4" Mod. Double Deep Individual Racking 24 8 3-000-2775-1575-DD 6 Column 15 3/4" Mod. Double Deep Individual Racking 5 2 4 28 8 3-000-3225-1575-DD 7 Column 15 3/4" Mod. Double Deep Individual Racking 2 32 6 4 7 2 8 3-000-3675-1575-DD 8 Column 15 3/4" Mod. Double Deep Individual Racking 4 36 8 3-000-4125-1575-DD 8 2 9 Column 15 3/4" Mod. Double Deep Individual Racking 4 40 2 8 3-000-4575-1575-DD 10 Column 15 3/4" Mod. Double Deep Individual Racking 9 4 44 8 3-000-5025-1575-DD 11 Column 15 3/4" Mod. Double Deep Individual Racking 2 10 4 48 8 3-000-5475-1575-DD 12 Column 15 3/4" Mod. Double Deep Individual Racking 11 2 4 52 2 8 3-000-5925-1575-DD 13 Column 15 3/4" Mod. Double Deep Individual Racking 12 4 56 2 8 3-000-6375-1575-DD 14 Column 15 3/4" Mod. Double Deep Individual Racking 13 4 60 8 3-000-6825-1575-DD 2 15 Column 15 3/4" Mod. Double Deep Individual Racking 14 4 64 2 8 3-000-7275-1575-DD 16 Column 15 3/4" Mod. Double Deep Individual Racking 15 4 68 8 3-000-7725-1575-DD 2 17 Column 15 3/4" Mod. Double Deep Individual Racking 16 72


\*Note: Please verify that you have the correct number of parts before proceeding.

## PLEASE FOLLOW WRITTEN INSTRUCTIONS CAREFULLY

- 1. Find an open, flat area in which to assemble your racking. Carefully remove all components from the box and check all parts to verify package contents.
- 2. Arrange the end ladders on the floor so that the bottle support pieces face one another. Attach spacer bar to top and bottom.



\*Tip: Begin with back of rack



Top Spacer Bar

**Bottom Spacer Bar** 

- 3. Attach middle ladders if applicable.
- 4. Flip and repeat for reverse side.

\*Note: For more stability attach racks to wall.