
Configuration Options Split Systems


1. Split Configuration

COLD AIR (Exhaust) RETURN AIR (Intake) Evaporator EVAPORATOR CONDITIONED SPACE or EXTERIOR (Sx Only) LINE SET WINE CELLAR HOT AIR (Exhaust) FRESH AIR (Intake) Unit

2. Split Ducted



3. Water Cooled Split



4. Water Cooled Split Ducted

